




- ☐ NEW
- ☐ supplement to .....
- ☒ replaces 2.A123-990201-ENG



## 2.+4.+6. A123 - MFT-H-2/ENG

### Operating Instructions MFT-H

### Handy for MFT/MFT2 actuators







## Safety notes on using the MFT-H

- When connecting-up to the actuator circuit, take great care not to allow the connecting lead to come into contact with mains power. Also ensure correct terminal assignment.
- The MFT-H is not isolated electrically from the RS232 interface or the actuator.
- Only approved computers that provide electrical isolation from the mains may be connected to the RS232 interface.
- Use only leak-proof alkaline batteries of Size AA (Mignon, LR6: dimensions 50x14 mm) or suitable NiCd or NiMH rechargeable batteries.
- All four units must be replaced at the same time when changing the batteries.
- Ensure correct polarity when fitting the batteries. Always use four identical batteries of the same make and type.
- Remove the batteries if the MFT-H is to remain unused for an extended period of time
- The device contains no replaceable components apart from the batteries.

## Fitting the batteries

1. Turn the MFT-H over to expose the back.
2. Open the battery compartment with a screwdriver or coin.
3. Fit the batteries in the compartment as indicated by the markers and close the compartment again.



## Actuators parameterisable with MFT-H

All multifunctional and bus-capable actuators (MFT- / MFT2 actuators as well as the VAV compact NMV-D2M) can be parameterised with the MFT-H. The damper actuator AM24-SR (multifunctional, but not bus-capable) can also be parameterised with the MFT-H.

## What do 'MFT' and 'MFT2' mean?

MFT and MFT2 actuators employ **Multi Function Technology** and both types can be parameterised using the MFT-H Handy parameter assignment device. MFT(2) actuators can be controlled either conventionally or through the Belimo MP-Bus system. The actuator AM24-SR is not bus-capable. When used in a bus system each MFT / MFT2 actuator can also be linked to a sensor. The value provided by the sensor is acquired by the actuator and transferred to the MP-Bus system. MFT actuators can be linked to active sensors (DC 0-10 V output) and ON/OFF switches. MFT2 actuators can also be linked to passive resistance-type sensors (e.g. Pt 1000 devices). More information on sensor linking will be found in Product Information Document 2. + 6. MFT2-1.

## Important: Assigning parameters to MFT(2) damper actuators

MFT(2) actuators (**Multi-Function Technology**) undergo basic parameter assignment for standard applications before being despatched from the factory. When necessary for his own purposes, the user can make on-site alterations to MFT(2) actuator parameters using the MFT Handy. However, when such reassignment of parameters is undertaken, the user will be responsible for ensuring that the settings are correct so as to provide proper functioning of the MFT(2) actuators. The final values of any new parameters should be marked on the MFT(2) actuators upon completion.

Brief description MFT-H	4
Technical data / Accessoires	4
Connection options / Wiring	5
Powering up/down, Fault alarms	6
Using the tree-menus	7
Tree menu: NM24-MFT(2) AM24-MFT(2), AM24-SR GM24-MFT(2)	8
Tree menu: LF24-MFT(2) AF24-MFT(2)	9
Tree menu: NV24-MFT(2) NVF24-MFT(2) NVF24-MFT(2)-E	10
Tree menu: NMV-DM2	11

## Description of menu functions Actuator A

A1 Default functions	12-13
A2 Modify / A2.1 Control	14
A2 Modify / A2.2 Feedback	15
A2 Modify / A2.3 Motion	16
A2 Modify / A2.4 Copy	17
A2 Modify / A2.5 Reset	17
A3 Service	18
MFT-H settings E	19
MP - adresssing	20


## Example of parameter assignment

Example of an SRS function	21
----------------------------	----

## Appendix

Instructions for a Handy software upgrade	22-23
--	-------

Operating controls







**Operating controls**

① **ON/OFF** switch and display illumination

② **ESC** Escape Key


③ **SET** Memory Key

④   Direction Keys

⑤   Direction Keys

⑥ **LCD Display**

⑦ **RS232 connection**

⑧ 

**Action**

Press to toggle On and Off  
Press for at least 2 s to illuminate display (MFT-H must be powered up first)

Press briefly once to move back one level in the menu  
Press for at least 2 s to return to the main menu

Jump to selected menu  
Enter selected command

For moving the cursor to the next line or the previous line of the menu. When there are up to 3 selected steps per menu, the cursor will jump from line to line. When there are more than 3 selected steps it will scroll one line at a time each time a key is pressed. The longer the keys are held depressed the faster will be the scrolling.  
An audible signal is given when the last line of the menu is reached with the key pressed.

For selecting steps in the menus when there are several side-by-side.

4-line

Level converter PP or MP to RS232


Software upgrade MFT-H

Connection to MFT(2) actuator

**Parameter assignment by MFT-H**  
MFT(2) actuators (Multi-Function Technology) undergo basic parameter assignment for standard applications before being despatched from the factory. When necessary, on-site alterations can be made to MFT(2) actuator parameters using the MFT-H Parameter Assignment Device. The kind of functions that can be set depends on the type of MFT(2) actuator being used.

**Checking service functions with the MFT-H**  
The MFT-H can be used for checking the functions of MFT(2) actuators. Either the values that have been previously assigned can be read out or the actuator itself can be operated with the MFT-H in order to check its functions.

**Operating the MFT-H**  
No special knowledge of programming is needed. The device is used interactively by means of its 4-line display and keypad. The procedure is based on the menu method which guides the operator through the tree menu step-by-step. It almost completely eliminates any chance of making mistakes. In the various menus and sub-menus the operator can define the functions or parameters required. Implausible values will not be accepted by the MFT-H.  
The language of communication to be used by the device can be preselected.

Technical data	MFT-H
Power supply	4 ordinary Mignon alkaline batteries 1.5 V, AA Size, LR6 or rechargeable NiCd batteries can be used
Minimum voltage	An alarm appears on the display if the battery voltage falls below 4.2 V
Connections	
• Power and PP/MP	3-pole motor plug-connector
• RS232	D-Sub 9 pole / female
Display	LCD 4-line
Communications	PP/MP
Safety class	 (safety extra-low voltage)
Ambient temperature range	0 °C...+50 °C
Maintenance	Maintenance-free
Case	ABS plastic (210 x 100 x 50 mm)
Weight	350 g


Accessories included	MFT-H – SET
<ul style="list-style-type: none"><li>• 1 Special adapter with compression terminals, type MFT-C</li><li>• 1 Motor connecting lead, 2-pole with motor plug-connector and two 4 mm dia. plugs</li><li>• 1 Power pack 24 V, type ZN230-24</li><li>• 4 Mignon alkaline batteries</li><li>• 2 Sheets of labels with 48 stickers on each (Item No. 31720) incl. Waterproof felt-tip pen</li></ul>	

**Optional (Not included in the MFT-H - SET)**

Motor plug-connector, 3-pole for customised connecting lead, Item No. 11783






**Tree menu (principle)**



**The MFT-H as level converter**

The MFT-H can be used as a level converter between RS 232 and PP interfaces (ZIP function).



## Powering up/down

When an MFT-H Handy is powered up it is first initialised and the version of software with which it is loaded is displayed.



The subsequent behaviour of the Handy varies according to whether it is a first commissioning or a restart:

### First power-up/First commissioning:


When a Handy is powered up for the first time it jumps directly to the "Language" menu after initialising. This allows the appropriate language of use to be selected.



### Restart:


#### – on the same actuator:

When the Handy is powered up again it jumps to the same menu item that it was at before it was powered down, provided it is connected to the same actuator as before (i.e. the Serial No. and Address correspond).



#### – on a different actuator:

If a different actuator is connected to the Handy before it is powered up again the fault alarm "No actuator" appears on the display and an audible beep signal is given. If the actuator has already been addressed, enter the correct address under "Search" on the menu and the Handy will find the actuator in question. Otherwise it will first be necessary to assign an address to the actuator; see "Addressing", Page ... .



### Auto power-down:


If, when a Handy is in use, none of its keys is pressed for a period of 5 minutes, it will power down automatically.

## Fault alarms

Any faults that occur are always identified by an alarm on the display and also by an audible beep signal.

### Alarms for exhausted batteries

When its batteries become exhausted (<4.2 V) the Handy generates an alarm on its display in the form of a flashing battery symbol. In order to avoid any loss of data the batteries must be replaced without delay.



If necessary, the alarm signal can be acknowledged with the **SET** key so that any parameter assignment task that has been started can be completed first. Although the status message will disappear from the display the battery symbol will continue flashing. If the batteries are not replaced the fault alarm will appear again as soon as the Handy is powered up again.

## Communication and system fault alarms

Message	Possible causes of faults	Fault rectification
No actuator	Wiring error	<ul style="list-style-type: none"> <li>• Check wiring</li> <li>• Check address</li> <li>• Repeat command</li> </ul>
No reply from actuator		
Defective transmission		
Programming error		
No EEPROM access	MFT(2) actuator defective	Change MFT(2) actuator
Command not recognised	MFT-H software version does not match that of the MFT(2) actuator	Ascertain software versions of MFT-H and MFT(2) actuator and consult Belimo
Enter password: ....	Input is password-protected	Enter password and start
Access denied	Belimo-barred input	Contact Belimo

## Specific configuration table













According to the particular application each MFT(2) actuator has a specific configuration table and the corresponding preset values stored in its memory.

This configuration determines which menu items in the MFT-H Handy can be selected and which values can be modified.

As soon as the Handy is connected to an MFT(2) actuator it downloads the data configuration from the actuator.

## Four different tree-menus


For parameter assignment purposes there are four different tree-menus available for different groups of products which the user can turn to for assistance when he is parameterising a particular actuator:

1	<p><b>Tree-menu for parameterising MFT(2) damper actuators without a safety function</b></p> <div>    </div> <div> <div>NM24-MFT(2)</div> <div>AM24-MFT(2)</div> <div>GM24-MFT(2)</div> </div> <div> <div>8 Nm</div> <div>18 Nm</div> <div>36 Nm</div> </div> <div> <p>Tree-menu see page 8</p> <p>Tree-menu also valid for AM24-SR</p> </div>
2	<p><b>Tree-menu for parameterising MFT(2) damper actuators with a safety function</b></p> <div>    </div> <div> <div>LF24-MFT(2)</div> <div>AF24-MFT(2)</div> </div> <div> <div>4 Nm</div> <div>15 Nm</div> </div> <div> <p>Tree-menu see page 9</p> </div>
3	<p><b>Tree-menu for parameterising MFT(2) valve actuators NV... without and NVF... with a safety function</b></p> <div>      </div> <div> <div>NV24-MFT(2)</div> <div>NVF24-MFT(2)</div> <div>NVF24-MFT(2)-E</div> </div> <div> <div>800 N</div> <div>800 N</div> <div>800 N</div> </div> <div> <p>Tree-menu see page 10</p> </div>
4	<p><b>Tree-menu for parameterising VAV-Compact NMV-D2M</b></p> <div>  </div> <div> <div>NMV-D2M</div> </div> <div> <div>8 Nm</div> </div> <div> <p>Tree-menu see page 11</p> </div>

Tree-menu for parameterising MFT(2)  
damper actuators without a safety function  
and for the AM24-SR



NM24-MFT(2)	AM24-MFT(2)	GM24-MFT(2)
8 Nm	18 Nm	36 Nm




Menu does not appear  
when "VAV (6 ± 4 V)" is  
selected under Basic  
Functions!

- ① Operating time, active time, Stop/Go ratio
- ② When the angle of rotation is limited mechanically the angle must be adapted electronically in order to ensure the proper functions
- ③ HW + SW direction of rotation changes produce virtual changes for switching points and Z control (= position settings are reversed)
- ④ Not for AM24-SR
- ⑤ AM24-SR cannot be addressed



**Tree-menu for parameterising MFT(2) damper actuators with a safety function**

**LF24-MFT(2)**    **AF24-MFT(2)**  
4 Nm                      15 Nm



Menu does not appear when "VAV (6 ± 4 V)" is selected under Basic Functions!


① Operating time, active time, Stop/Go ratio  
 ② When the angle of rotation is limited mechanically the angle must be adapted electronically in order to ensure the proper functions  
 ③ HW + SW direction of rotation changes produce virtual changes for switching points and Z control (= position settings are reversed)

# Tree menu for NV24-MFT(2), NVF24-MFT(2)(-E)

Tree-menu for parameterising MFT(2) valve actuators NV... without and NVF... with a safety function



NV24-MFT(2) 800 N    NVF24-MFT(2) 800 N    NVF24-MFT(2)-E 800 N




- ① Operating time, active time, Stop/Go ratio  
 ② With NVF... actuators the actuating force cannot be modified (the appropriate menus do not appear).  
 ③ HW + SW direction of rotation changes produce virtual changes for switching points and Z control (= position settings are reversed)


## Tree-menu for parameterising VAV-Compact NMV-D2M



NMV-D2M  
8 Nm



- ① Operating time, active time, Stop/Go ratio
- ② When the angle of rotation is limited mechanically the angle must be adapted electronically in order to ensure the proper functions
- ③ HW + SW direction of rotation changes produce virtual changes for switching points and Z control (= position settings are reversed)
- ④ Settings for the electrical working range for volumetric flow.
- ⑤ Settings for the U5 voltage signal output for 0...100% nominal volumetric flow.
- ⑥ Reference value and actual value as % of nominal volumetric flow.  
Calculation of actual volumetric flow [m³/h]:  
 $V_{ACT} [m³/h] = V_{NOM} [m³/h] / 100 \times V_{ACT} [\%]$
- ⑦ The set value of running time has no effect on normal control. Settings are only active for override control.




In the **Default functions** branch of the tree menu it is possible to assign so-called ‘default’ or standard functions to MFT(2) actuators. For each default function a data record containing the normal standard parameters for the function is stored. The appropriate function can be selected with the **▼ ▲** direction keys. Pressing the **SET** key enters the function into the actuator together with its data record. A warning appears on the display first which must be acknowledged by pressing the **SET** key again.

**A1.1 Default function SR (DC 2...10 V)**  
Selecting this function parameterises the MFT(2) actuator for the modulating mode.

Default functions  
>SR(2-10V DC )  
PWM(0.59-2.93s)  
3-point

Display




Data record SR (DC 2...10 V) (Example AM24-MFT(2))		
Working range	2...10 V DC	
Function		
Feedback U5	2...10 V DC	
Torque	18 Nm min.	
Angle of rotation	95°	
Running time	150 s	
Angle of rotation adaption	none	
Overrides	Min. (min. position)	= 0%
(referred to full angle of rotation 95°)	IP (intermediate position)	= 50%
	Max. (max. position)	= 100%

**A1.2 Default function PWM (0.59-2.93s)**  
Selecting this function parameterises the MFT(2) actuator for the PWM mode.

Default functions  
>SR(2-10V DC )  
>PWM(0.59-2.93s)  
3-point

Display



**Explaining PWM control:**  
PWM does not mean ‘pulse width modulation’ in its normal sense. The actuator measures the length of the control pulse and then moves to the corresponding position. So far, PWM-type actuators are only being used in the USA. Depending on the type of actuator, the user can define various PWM ranges.

**Examples of PWM control** when a PWM range of 0.59-2.93s has been selected for the actuator:

*Example 1, 100% angle of rotation*  
When a pulse of 2.93s duration is sent to the actuator it causes it to move to the 100% angle-of-rotation position. (If the pulses sent to the actuator are of longer duration than 2.93 s the actuator will also move to the 100% angle-of-rotation position).

*Example 2, 50% angle of rotation*  
When a pulse of 0.59s + (2.93s - 0.59s) / 2 = 1.17s + 0.59s duration is sent to the actuator it causes it to move to the 50% angle-of-rotation position.

*Example 3, 0% angle of rotation*  
When a pulse of 0.59 s duration is sent to the actuator it causes it to move to the 0% angle-of-rotation position. (If the pulses sent to the actuator are of shorter duration than 0.59s but longer duration than 20 ms the actuator will also move to the 0% angle-of-rotation position; at less than 20 ms there is no defined function).

Data record PWM (0.59-2.93s) (Example AM24-MFT(2))	
Control signal Y	PWM
Working range	0.59-2.93s
Function	
Feedback U5	2...10 V DC
Torque	18 Nm min.
Angle of rotation	95°
Running time	150 s
Angle-of-rotation adaption	none


## A1.3 Default function 3-point

Selecting this function parameterises the MFT(2) actuator for the 3-point control mode.

Default functions  
SR(2-10V DC )  
PWM(0.59-2.93s)  
>3-point

Display

### Wiring diagram 3-point



### Data record 3-point (Example AM24-MFT(2))

Control signal Y	3-point
Function	
Feedback U5	DC 2...10 V
Torque	18 Nm min.
Angle of rotation	95°
Running time	150 s
Angle of rotation adaption	none


## A1.4 Default function Open/Close

Selecting this function parameterises the MFT(2) actuator for the Open/Close mode

Default functions  
PWM(0.59-2.93s)  
3-point  
>Open/Close

Display

### Wiring diagram Open/Close



### Data record Open/Close (Example AM24-MFT(2))

Control signal Y	Open/Close
Function	
Feedback U5	DC 2...10 V
Torque	18 Nm min.
Angle of rotation	95°
Running time	150 s
Angle of rotation adaption	none


## A1.5 Default function VAV (6 ± 4V)

Selecting this function parameterises the MFT(2) actuator for the VAV control mode.

Default functions  
3-point  
Open/Close  
>VAV (6±4V)

Display

### Wiring diagram VAV




### Data record VAV (6 ± 4V) (Example AM24-MFT(2))

Control signal Y	From VAV controller
Function	
Feedback U5	DC 2...10 V
Operating range	6 ± 4V
Torque	18 Nm min.
Angle of rotation	95°
Running time	150 s
Angle of rotation adaption	none

The **Modify** branch of the tree menu allows the values and functions of an MFT(2) actuator to be custom-parameterised when necessary (see p. 21 Example of parameter assignment).

When the **Modify** branch of the menu is first entered it will always show the values and functions that were given to an MFT(2) actuator the last time it was assigned parameters. If a modification of a particular default function (A1.x) only involves changing a few individual values from their default settings, it is advisable to load the MFT(2) actuator with the appropriate default function (see page 12) before making the modification.


## A2.1 Control



Control	<b>A2.1</b>	Control allows appropriate working ranges to be defined for control modes
DC control	<b>A2.1.1</b>	Selection of modulating control: The settings correspond to the electrical working range for 0...100% angle of rotation or stroke, in the case of VAV-Compact NMV-D2M = 0...100% nominal volumetric flow ( $V_{NOM}$ ) effect on working range if <b>MAX</b> and/or <b>MIN</b> positions (see Page 16, A2.3.4) are selected. The working range corresponds to the control range set with the MIN and MAX positions. The set <b>MIN position</b> corresponds to the Start point of the working range. The set <b>MAX position</b> corresponds to the Finish point of the working range. (For the VAV-Compact NMV-D2M the MIN position corresponds to the minimum volumetric flow $V_{MIN}$ and the MAX position to the maximum volumetric flow $V_{MAX}$ )
DC 2 – 10 V (Default)	A2.1.1a	Selection of a fixed working range DC 2...10 V (as per SR (DC 2-10 V) see page 12, Section A1.1)
DC 0 – 10 V	A2.1.1b	Selection of a fixed working range DC 0.5...10 V
DCV variable	A2.1.1c	Variable definition of a working range : • Start DC 0.5...30.0 V; Finish DC 2.5...32.0 V • For the VAV-Compact NMV-D2M : Start point DC 0...30.0 V and Finish point DC 2.0...32.0 V Finish must be at least 2 V above Start!
Start Stop		
PWM control	<b>A2.1.2</b>	Selection of PWM control (MFT(2) actuator parameterised for PWM control) (see page 12, A1.2 Explaining PWM control)
0.02 – 5s	A2.1.2a	Selection of a fixed PWM working range of 0.02...5s
0.59 – 2.93s	A2.1.2b	Selection of a fixed PWM working range of 0.59...2.93s
0.1 – 25.5s	A2.1.2c	Selection of a fixed PWM working range of 0.1...25.5
PWM variable	A2.1.1d	Variable definition of a PWM working range: PWMmin. 0.02 s..... PWMmax. 50.00 s
PWmin PWmax		
3-point	<b>A2.1.3</b>	Selection of 3-point control. MFT(2) actuator parameterised with data record for 3-point actuator (see page 13, Section A1.3)
Open/Close	<b>A2.1.4</b>	Selection of Open/Close control. MFT(2) actuator parameterised with data record for Open/Close actuator (see page 13, Section A1.4)

The mode of control required is selected with the direction keys and a variable working range with the direction keys and . Pressing the **SET** key either causes the menu to jump to the next sub-menu or the selected values are entered into the actuator.


## A2.2 Feedback




Feedback	<b>A2.2</b>	The <b>Feedback</b> branch of the tree menu allows the function of the <b>[5]—U<sub>5</sub> →</b> feedback signal to be defined.				
Voltage U	<b>A2.2.1</b>	Selection of feedback signal U <sub>5</sub> as a modulating linear DC measured voltage: The defined signals correspond to 0...100% angle of rotation or stroke. For the NMV-D2M the signals correspond to the actual value of volumetric flow in 0...100% referred to V <sub>NENN</sub> .				
DC 2 – 10 V (Default)	<b>A2.2.1a</b>	Select a fixed range of DC 2...10 V	<b>[5]—U<sub>5</sub> →</b>			
DC 0 – 10 V	<b>A2.2.1b</b>	Select a fixed range of DC 0.5...10 V	<b>[5]—U<sub>5</sub> →</b>			
DCV variable	<b>A2.2.1c</b>	Variable definition of the DC measuring voltage signal: <ul style="list-style-type: none"><li>• Start DC 0.5... 8.0 V; Finish DC 2.5... 10.0 V</li><li>• For the VAV-Compact NMV-D2M: Start point DC 0...8.0 V and Finish point DC 2.0...10.0 V</li></ul> Finish must be at least 2 V above Start!				
Start .....						
Stop .....						
Softswitch S ②	<b>A2.2.2</b>	Select feedback signal U <sub>5</sub> as softswitches S1 and S2. Referred to the effective mechanical angle of rotation or stroke of the MFT(2) actuator, it is possible to define 2 soft switching points (S1 and S2). The level of the DC voltage of U <sub>5</sub> varies according to the angle of rotation or stroke executed and the S1 or S2 switching points reached. <table><tr><td>Actuator position below set value of S1 : Level U<sub>5</sub> = constant DC 4 V</td></tr><tr><td>Actuator position above set value of S1 and below set value of S2 : Level U<sub>5</sub> = constant DC 7 V</td></tr><tr><td>Actuator position above set value of S2 : Level U<sub>5</sub> = constant DC 10 V</td></tr></table>		Actuator position below set value of S1 : Level U <sub>5</sub> = constant DC 4 V	Actuator position above set value of S1 and below set value of S2 : Level U <sub>5</sub> = constant DC 7 V	Actuator position above set value of S2 : Level U <sub>5</sub> = constant DC 10 V
Actuator position below set value of S1 : Level U <sub>5</sub> = constant DC 4 V						
Actuator position above set value of S1 and below set value of S2 : Level U <sub>5</sub> = constant DC 7 V						
Actuator position above set value of S2 : Level U <sub>5</sub> = constant DC 10 V						
S1 .....						
S2 .....	<b>A2.2.2a</b>	Set softswitches S1 and S2 (adjustable 1...99%) <b>Value of S2 must always be set at least 10% higher than value of S1.</b>				
Alarms	<b>A2.2.3</b>	Assign maintenance or fault alarms to feedback signal U <sub>5</sub> . Various criteria that output a maintenance or fault alarm on U <sub>5</sub> can be defined. Depending on whether maintenance or fault has been defined for the criteria A2.2.3a - A2.2.3d, U <sub>5</sub> outputs a specific signal when one of the criteria occurs.				
<div>② When the angle-of-rotation is limited mechanically (&lt;95°) the angle must be adapted electronically in order to ensure the proper functions.</div> <div><div><p>U<sub>5</sub> Signal for <b>normal mode</b> (no maintenance or fault alarm, level = constant DC 3 V)</p></div><div><p>U<sub>5</sub> Signal for <b>maintenance alarm</b></p></div><div><p>U<sub>5</sub> Signal for <b>fault alarm</b></p></div></div> <div>Note: Any existing <b>maintenance alarms</b> will be cancelled when the MFT(2) actuator is disconnected from the power supply. However, maintenance alarms can also be cancelled with the MFT-H device (see page 18, Section A3.6). • Any existing <b>fault alarms</b> can only be cancelled with the MFT-H device (see page 18, Section A3.6)</div>						
Stop/Go-Ratio	<b>A2.2.3a</b>	Criterion <b>actuator hunting</b> (typical cause: unstable control) selectable as maintenance or fault alarm. <b>Stop/Go-ratio</b> is the ratio [%] of active time to operating time (operating time = No. of hours actuator connected to power supply. Active time = No. of hours MFT(2) actuator in mechanical motion while connected to power supply). A maintenance or fault alarm is generated if the <b>Stop/Go-ratio</b> exceeds a value of 20% (see also explanations on page 18, Section A3.5 Data log)				
Mech. Overlast ②	<b>A2.2.3b</b>	Criterion <b>mechanical overload</b> (actuator stationary) selectable as maintenance or fault alarm.				
Travel ②	<b>A2.2.3c</b>	Criterion <b>mechanical travel changed 10%</b> selectable as maintenance or fault alarm.				
Alarms & U	<b>A2.2.4</b>	Combination of maintenance or fault alarms A2.2.3a – A2.2.3d and modulating DC measuring voltages A2.2.1a – A2.2.2b selectable. If a maintenance or fault alarm criterion is exceeded, the DC measuring voltage signal for the maintenance or fault signal are overridden.				
Alarms & S	<b>A2.2.5</b>	Combination of maintenance or fault alarms A2.2.3a – A2.2.3c and softswitches S1 and S2 A2.2.2a – A2.2.2b selectable. If a maintenance or fault alarm criterion is exceeded, the softswitch signals for the maintenance or fault signal are overridden.				

The feedback function required is selected with the directions keys **◀ ▶** and variable values are set with the direction keys **▼ ▲** and **▼ ▲**. Pressing the **[SET]** key either causes the menu to jump to the next sub-menu or the selected values are entered into the actuator.






Motion	<b>A2.3</b>	The <b>Motion</b> branch of the tree menu allows the motion, running time and angle-of-rotation or stroke functions of the MFT(2) actuator to be defined.	
Torque	<b>A2.3.1</b>	Select the torque or force of the MFT(2) actuator (not possible in the case of MFT(2) actuators with springs)	
100 %	<b>A2.3.1a</b>	Set torque or force to 100% (default value). Example: AM24-MFT(2) = 18 Nm	
75 %	<b>A2.3.1b</b>	Set torque or force to 75% of default value. Example: AM24-MFT(2) = 13.5 Nm	
50 %	<b>A2.3.1c</b>	Set torque or force to 50% of default value. Example: AM24-MFT(2) = 9 Nm	
25 %	<b>A2.3.1d</b>	Set torque or force to 25% of default value. Example: AM24-MFT(2) = 4.5 Nm	
Running time	<b>A2.3.2</b>	Select running time of MFT(2) actuator	
Standard	<b>A2.3.2a</b>	Set running time for 100% angle of rotation or stroke as default value. Example: AM24-MFT(2) = 150 s	
Variable	<b>A2.3.2b</b>	Set running time for 100% angle of rotation or stroke anywhere within a range determined. Note: The torque [Nm] and sound power level [dB] of the MFT(2) actuator might vary if the running time is less than the default value. Refer to the appropriate function graphs in the product information on MFT(2) actuators. The adjustable range of running time depends of the connected MFT(2) actuator.	
...s 100 % Rotation			
Direction of rotation or lift	<b>A2.3.3</b>	<b>Select the direction of rotation or lift of the MFT(2) actuator.</b>	
Normal	<b>A2.3.3a</b>	Set the direction of rotation or lift according to the symbols on the direction-of-rotation switch on the housing of the MFT(2) actuator or the settings of DIL switch S3.2 (closing point) on the linear actuator.	
Reverse	<b>A2.3.3b</b>	Set the direction of rotation or lift opposite to the selected direction of rotation of the damper actuator or to the selected closing point of the linear actuator.	
Rotation ②	<b>A2.3.4</b>	* For damper actuators and valve actuators select override positions and/or angle-of-rotation or stroke limits. ** For the VAV-Compact NMV-D2M select override positions and volumetric flow limits. (For detailed functional descriptions see Product Information Documents * 2. + 6. MFT(2)-1 or ** 4. NMV-D2M-1)	
Minimum	<b>A2.3.4a</b>	Enter the MIN position Adjustable: 0...100% referred to <b>MAX position</b> <b>Note:</b> In the case of the AM24-SR and their configuration variants AM24-0xx the MIN position is referred to 0...100% ↺ angle of rotation.	For the VAV-Compact NMV-D2M: Set $V_{MIN}$ Adjustable: 0...100% referred to preset $V_{MAX}$ .
Rotation ...%			
Intermediate	<b>A2.3.4b</b>	Enter the intermediate position. Adjustable: 0...100% referred to the control range set with the MIN and MAX positions	For the VAV-Compact NMV-D2M: Set $V_Z$ . Adjustable: 0...100% referred to the control range $V_{MIN}$ and $V_{MAX}$ .
Rotation ...%			
Maximum	<b>A2.3.4c</b>	Enter the MAX position Adjustable : 0...100% ↺ angle of rotation or stroke (in the case of the VAV-Compact NMV-D2M referred to the nominal volumetric flow $V_{NOM}$ ). <b>Note:</b> In the case of actuators with a mechanically limited angle of rotation (<95°) the angle of rotation must be electronically adapted in order to ensure that the function is active (see also Document 2. + 6. MFT2-1)	
Rotation ...%			
Adaption	<b>A2.3.5</b>	Select adaption (during adaption the measuring signal U5 is automatically adapted to the effective value of mechanical angle of rotation. The working range and the running time are adapted to the control range set with MIN and MAX).	
Off (Default)	<b>A2.3.5a</b>	<b>No adaption</b> (default)	
Manual	<b>A2.3.5b</b>	To trigger adaption • NM24-MFT(2), AM24-MFT(2), GM24-MFT(2) and NMV-D2M by pressing the manual pushbutton twice. • LF24-MFT(2) and AF24-MFT(2) by moving the L/R switch back and forth twice.	
Auto	<b>A2.3.5c</b>	Adaption triggered: Each power-up or when the functions described in A2.3.5b are implemented.	




The functions required are selected with the directions keys and the variable values are set with the direction keys . Pressing the **SET** key either causes the menu to jump to the next sub-menu or the selected values are entered into the actuator.




## A2.4 Copy



## A2.5 Reset




The functions required are selected with the directions keys **▼** **▲**. Pressing the **SET** key either causes the menu to jump to the next sub-menu or the selected functions are initiated.




The functions required are selected with the directions keys **▼ ▲** and **◀ ▶**. Pressing the **SET** key either causes the menu to jump to the next sub-menu or actuator data can be displayed, deleted or entered into the actuator.


## MFT-H settings E



MFT-H settings	<b>E</b>	Various modes of operation can be selected from the <b>MFT-H settings</b> branch of the tree menu.
Language	<b>E1</b>	MFT-H language of communication
German	<b>E1.1</b>	Select <b>German</b>
English	<b>E1.1</b>	Select <b>English</b>
further languages	<b>E1.3- E1.10</b>	currently in preparation
PP-interface	<b>E2</b>	MFT-H device in <b>PP-Interface</b> mode When the MFT-H device is switched to this mode, the display shows the message " <i>PP-Interface ready....</i> ". The MFT-H can now be used as a level converter between an RS232 interface and a PP interface (ZIPfunction).
Software	<b>E3</b>	Display of <b>Software version</b> loaded in MFT-H device
SW version		



The functions required are selected with the direction keys   and the variable values set with the directions keys   . Pressing the **SET** key either causes the menu to jump to the next sub-menu or the selected values are entered into the actuator.




**MP** The address of the actuator is entered in the **Addressing** branch of the menu.

**MP1** Either PP or 1...8 (MP addresses) can be selected in the “Address” menu.


- **The PP address (PP = Point-to-Point) is selected** if there is only one MFT(2) actuator connected to the Handy (see Diagram 1 or Diagram 2 on Page 5). When an actuator is addressed with PP it is automatically parameterised for the classic mode of operation (no MP-Bus). In this case its control in the classic mode can be either modulating, 3-point, Open/Close or PWM. PP addressing is also used to reset an actuator that has previously been set for bus operation to the classic mode.
- **MP addresses 1...8 (MP = Multi Point) is selected** if there are several MFT(2) actuators connected to the Handy via the MP-Bus (see Diagram 3 on Page 5). This is because when there are several MFT(2) actuators communicating over the MP-Bus each one must be clearly identifiable. When an MFT(2) actuator is addressed with an MP address 1...8 it is automatically parameterised for MP-Bus operation. In this case it is controlled digitally over the MP-Bus.

Procedure for addressing an MFT(2) actuator:

1. Preselect the required address with the keys (Example: MP address 4)




2. Press the **SET** key and the following display will appear...



3. Perform the appropriate reset function on the MFT(2) actuator from the table below and according to what the *Handy* demands.


Actuator family	Actuator type	Reset function
Actuators without spring return	NM24-MFT(2), AM24-MFT(2), GM24-MFT(2), NMV-D2M	Press manual pushbutton 1x
Actuators with spring return	LF24-MFT(2), AF24-MFT(2)	Move L/R switch back and forth 1x (within 4 s)
Linear actuators for valves	NV24-MFT(2), NVF24-MFT(2), NVF24-MFT(2)-E	Press key S2 1x (inside the housing cover)

4. The following display appears briefly to show that the appropriate address has been assigned to the MFT(2) actuator:



The required address will have been assigned to the actuator when this procedure has been completed.

⑤ **Notes on parameterising AM24-SR's**  
The AM24-SR and its configuration variants AM24-xx (e.g. AM24-001) do not have a bus capability and so cannot be addressed. In order to set their parameters these types can be accessed directly via the Actuator/Address menu. In this case “PP” must be selected as the address.



## Starting point for the examples of parameter assignment

Select menu  
>Actuator  
Data records  
MFT-H settings

- When the MFT-H device is powered up, it always jumps directly to the menu step that was selected when it was powered down. In the following Examples, parameter assignment always begins in the main menu. Press the **[ESC]** key for at least 2 seconds in order to access the main menu.
- During parameter assignment, the MFT(2) actuator must be connected to the MFT-H device as shown in Diagrams 1 or 2 (see page 5).

## 1. Example: Parameterising an SRS function with a AM24-MFT(2) actuator

### 1.1 Preparation

#### a) Definition of required parameters

Working range	DC 3.5...6.6 V
Function	
Feedback U5	DC 2...10 V
Torque	min. 18 Nm
Angle of rotation	95°
Running time	150 s
Angle-of-rotation adaption	none
Overrides	Min. (Min.Pos.) = 0%
(referred to the full	IP (Intermediate Pos.) = 50%
angle of rotation of 95°)	Max. (Max.Pos.) = 100%

#### b) Ascertain default function nearest to the final parameterising required.

To ascertain: The above data record is nearest to the default function SR (2...10 V DC). Therefore, the SR default function and the SR wiring diagram shown on page 12, Section A1.1 can be used as the basis.

### 1.2 Parameter assignment

#### a) Select menu

Press the **[ESC]** for 2 seconds.

Display

Select menu  
>Actuator  
Data records  
MFT-H settings

#### b) Select Actuator menu

Press the **[SET]** key.

Display

Actuator  
>Default functions  
Modify  
MFT-H settings

#### c) Select Default functions menu

Press the **[SET]** key

Display

Default functions  
>SR (DC 2...10 V)  
PWM(0,59-2,93s)  
3-point

#### d) Load default function SR (DC 2...10 V) into the MFT damper actuator.

Press the **[SET]** key

Display

Modify  
overwrite?  
SET=Execute  
ESC=Abort

Press the **[SET]** key

Display 1:  
during  
programming

Actuator being  
programmed...

Display 2:  
SR (DC 2...10V)  
programmed

Default functions  
>SR (DC 2...10 V)  
PWM(0,59-2,93s)  
3-point

A 2-beep signal gives audible confirmation...

#### e) Select Modify menu

Press the **[ESC]** key

Display

Actuator  
>Default functions  
Modify  
Service

Press the **[V]** key

Display

Actuator  
>Default functions  
Modify  
Service

Press the **[SET]** key

Display

Modify  
>Control  
Feedback  
Motion

#### f) Select Control menu

Press the **[SET]** key

Display

Control  
>Control signal DCV  
Control signal PWM  
3-point

#### g) Select Control signal DCV menu

Press the **[SET]** key

Display 1:  
during  
programming

Actuator being  
programmed...

Display 2:  
Control signal DCV  
has been loaded....

Control signal DC V  
>DC 2-10 V  
DC 0-10 V  
DCV variable

A 2-beep signal gives audible confirmation...

#### h) Selected DC variable menu

Press the **[V]** key twice until the cursor is opposite DC variable.

Display

Control signal DCV  
DC 2-10 V  
DC 0-10 V  
>DCV variable

Press the **[SET]** key

Display

DCV variable  
Start Finish  
> 2.0V 10.0V  
ESC = Abort

#### i) Program SRS range

Hold the **[A]** key depressed until Start shows 3.5 V.

Display

DCV variable  
Start Finish  
> 3.5V 10.0V  
ESC = Abort

Press the **[R]** key

Display

DCV variable  
Start Finish  
3.5V >10.0V  
ESC = Abort

Hold the **[V]** key depressed until Finish shows 6.6 V.

Display

DCV variable  
Start Finish  
3.5V >6.6V  
ESC = Abort

Press the **[SET]** key

Display 1:  
during  
programming

Actuator being  
programmed...

Display 2:  
Working range  
DC 3.5V-6.6 V  
programmed.

DCV variable  
Start Finish  
3.5V >6.6V  
ESC = Abort

A 2-beep signal gives audible confirmation...

**k) Labelling:** Upon completion of programming, attach a label to the MFT(2) actuator showing the customised data (not identical to the AM24-SR basic type). A waterproof felt-tip pen will write on the special stickers provided (use 2 stickers if necessary).

Working range =  
DC (3,5-6,6V)

Data record parameterised

# Instructions for a Handy software upgrade

Before a software upgrade can be carried out a binary file containing the whole menu and the languages (Version 2.0 has German and English only, other languages are in preparation) must be loaded into the Handy. Use the "download20.exe" download program for this purpose.

The program can be started directly from the floppy disk (1.44 MB) or the hard disk.


## System requirements and accessories needed:

- PC with **Windows 95/98/NT/2000** and at least 8 MB of RAM
- Available serial interface **COM1** or **COM2**
- Mouse for operating the software
- RS232 lead, for monitors, D-Sub 9-pin, male/female (no core crossing)


## Procedure for upgrading MFT-H Handy's:

Remove the red cap from the interface connector on the Handy and use the 9-pin D-Sub lead to connect to one of the PC's serial interfaces COM1 or COM2.


Start the download program **download20.exe** from the hard disk or floppy and activate the appropriate interface, e.g. **COM2**.



In the menu, click on **[Download] [Load file]** or  and ....



....open the binary file, e.g.  
<<mft-h-v20.bin>>



The file will have been loaded successfully if the <<ready to program>> message appears.

## Preparing the Handy

Switch on the Handy and wait until it has finished its startup cycle (first-time Handy's jump to [Language] in the menu).

Select [MFT-H settings] in the menu and change to the [Software] menu.


Pressing **all 4 arrow keys** on the Handy at the same time for at least two seconds will cause the display to change to the hidden menu [SW Upgrade].

Select [Execute]

**Note:** Activating "Execute" deletes the old software immediately. This means that the Handy can no longer be used until the new software has been loaded.

## Loading a Handy with its new software

The message below and a flashing arrow (bottom right) indicate that the Handy is ready for the software download.

Downloading is started by using the mouse to click on [Download] and then [Start] or . Download status is indicated at 'Progress' by means of a moving bar. While this function is in progress a solid square in the bottom right-hand corner of the Handy display will be flashing. Wait until the following status message appears (this may take a few minutes):




The Handy has now been successfully upgraded. It will then restart, give a single short beep and change to the Start Menu.

## Programming other Handy's

If there are other Handy's to be upgraded with new software simply plug in the next one with the RS232 lead and proceed again as described above.

## Errors during upgrading


Should downloading be impossible for any reason the following status message will appear on the display:



Check the following points:

- Is there a proper connection between the Handy and the appropriate serial interface COM1 or COM2?
- Are you sure there is really no core crossing in the RS232 lead?
- Is the Handy switched on and in SW Upgrade mode? (Is the arrow in the bottom right-hand corner of the display flashing?)

If everything appears to be OK, click on [Start] in the [Download] menu again. If it still does not work, switch the Handy off and on again, close the download software on the PC and restart it.





## Air applications




Standard actuators and spring-return actuators for air control dampers in HVAC systems



Safety actuators for motorizing fire and smoke extraction dampers



VAV systems for individual room air control



Mixing actuators and motorized ball valves for HVAC water circuits



Globe valves and intelligent linear actuators – also for leading makes of valve

# Innovation, Quality and Consultancy: A partnership for motorizing HVAC actuators

Contact the following for further information:

### Belimo Headquarters

CH BELIMO Holding AG  
Brunnenbachstrasse 1  
8340 Hinwil, Switzerland  
Tel. +41 (0)43 843 61 11  
Fax +41 (0)43 843 62 68  
info@belimo.ch  
www.belimo.ch

### Belimo Subsidiaries

AT/ BELIMO Automation  
HR/ Handels-gesellschaft m.b.H.  
HU/ Geiselbergstrasse 26-32  
SI/ 1110 Wien, Austria  
SK Tel. +43 (0)1 749 03 61-0  
Fax +43 (0)1 749 03 61-99  
info@belimo.at

AU BELIMO Actuators Pty. Ltd.  
Unit 10, 266 Osborne Avenue  
Clayton South, VIC 3169  
Australia  
Tel. +61 (0)3 9551 0201  
Fax +61 (0)3 9551 0215  
belimo@belimoactuators.com

CA BELIMO Aircontrols (CAN), Inc.  
5716 Coopers Ave., Units 14&15  
Mississauga, Ontario L4Z 2E8  
Canada  
Tel. +1 (1)905 712 31 18  
Fax +1 (1)905 712 31 24  
webmaster@belimo.com

CH BELIMO Automation AG  
Sales Switzerland  
Brunnenbachstrasse 1  
8340 Hinwil, Switzerland  
Tel. +41 (0)43 843 62 12  
Fax +41 (0)43 843 62 66  
info@belimo.ch  
www.belimo.ch

DE BELIMO Stellantriebe  
Vertriebs GmbH  
Welfenstr. 27, Postfach 72 02 30  
70599 Stuttgart, Germany  
Tel. +49 (0)711 1 67 83-0  
Fax +49 (0)711 1 67 83-73  
info@belimo.de  
www.belimo.de

ES BELIMO Iberica  
de Servomotores, S.A.  
C/San Romualdo, 12-14  
28037 Madrid, Spain  
Tel. +34 91 304 11 11  
Fax +34 91 327 25 39  
info@belimo.es

FR BELIMO Servomoteurs  
Z.A. de Courtry  
33, Rue de la Régale  
77181 Courtry, France  
Tel. +33 (0)1 64 72 83 70  
Fax +33 (0)1 64 72 94 09  
mail@belimo.fr

GB BELIMO Automation UK Limited  
The Lion Centre  
Hampton Road West  
Feltham, Middlesex, Great Britain  
TW 13 6DS  
Tel. +44 (0)20 8755 4411  
Fax +44 (0)20 8755 4042  
belimo@belimo.co.uk

HK BELIMO Actuators Ltd.  
Room 208, 2/F  
New Commerce Centre  
19 On Sum Street, Shatin, N.T.  
Hong Kong  
Tel. +852 26 87 17 16  
Fax +852 26 87 17 95  
info@belimo.com.hk

PL BELIMO Słowinski S.A.  
ul. Zagadki 21  
02-227 Warszawa, Poland  
Tel. +48 (0)22 886 53 05  
Fax +48 (0)22 886 53 08  
info@belimo.pl

SG BELIMO Actuators Pte Ltd  
2, Jurong East Street 21  
#04-31F IMM Building  
Singapore 609601  
Tel. +65 6564 9828  
Fax +65 6564 9038  
info@belimo.com.sg

US BELIMO Aircontrols (USA), Inc.  
43 Old Ridgebury Road  
P.O. Box 2928  
Danbury, CT 06810 USA  
Tel. +1 (1)203 791 99 15  
Fax +1 (1)203 792 29 67  
webmaster@belimo.com  
www.belimo.com

### Belimo Representatives and Agencies

AE BELIMO Trading  
Middle East Office  
P.O. Box 73885  
Dubai, U.A.E.  
Tel. +971 (0)4 295 9670  
Fax +971 (0)4 295 9680  
belimome@emirates.net.ae

BG BELIMO Bulgaria Ltd.  
j.k. Lagera, 3 Smolyanska Str.  
bl. 56, entr. B, ap. 50  
1612 Sofia, Bulgaria  
Tel. +3592 952 3470/1  
Fax +3592 545 995  
belimo@intech.bg

CN BELIMO Actuators Ltd.  
Room 1305, Financial Square  
No. 333 Jiujiang Road  
200001 Shanghai, China  
Tel. +86 21 6360 8980  
Fax +86 21 6360 8981  
shanghai@belimo.ch

CN BELIMO Beijing  
Rm 605, Beijing Hai Chang  
Edifice, 44, Liang Ma Qiao Road  
Chao Yang District  
100016 Beijing, China  
Tel. +86 10 6462 1382  
Fax +86 10 6462 1383  
beijing@belimo.ch

CY R.E.S. Ltd.  
P.O. Box 8297  
Nicosia, Cyprus  
Tel. +357 (0)2 51 10 07  
Fax +357 (0)2 49 65 47  
reliance@spidernet.com.cy

CZ BELIMO CZ (Ing. Ivar Mentzl)  
Charkovská 16  
10100 Praha 10, Czech Republic  
Tel. +420 (0)2 717 40 311  
Fax +420 (0)2 717 43 057  
info@belimo.cz

DK BELIMO A/S  
Thomas Helstedvej 7A  
8660 Skanderborg, Denmark  
Tel. +45 86 52 44 00  
Fax +45 86 52 44 88  
info@belimo.dk

EE BELIMO Balticum AS  
Turi 10 d  
11313 Tallinn, Estonia  
Tel. +372 6 140 811  
Fax +372 6 140 812  
info@belimo.ee

FI Oy Suomen BELIMO Ab  
Insinöörinkatu 2  
00810 Helsinki, Finland  
Tel. +358 (0)424 651 1  
Fax +358 (0)424 651 250  
belimo@belimo.fi

GR BELIMO Air Controls  
29, Tagm, Plessa, Kallithea  
GR 17674 Athens, Greece  
Tel. +30 2 10 94 00 766  
Fax +30 2 10 94 00 767  
belimogr@tee.gr

IE Safegard Systems Ltd.  
Systems House, Unit 34  
Southern Cross Business Park  
Bray, Co Wicklow, Ireland  
Tel. +353 (0)1 2761600  
Fax +353 (0)1 2761611  
info@safegard.ie

IL Shemer Representations  
P.O. Box 296  
56101 Yehud, Israel  
Tel. +972 3 536 51 67  
Fax +972 3 536 05 81  
shemer@shemerrep.co.il

IN BELIMO Vitek Air Controls  
C-114 Lancelot, First Floor  
S.V. Road, Borivali (West)  
Mumbai 400 092, India  
Tel. +91 22 5695 9439  
Fax +91 22 2806 2163  
bvac@bom2.vsnl.net.in

IS Hitataekni ehf.  
Langhóltsveg 109  
104 Reykjavík, Iceland  
Tel. +354 5 88 60 70  
Fax +354 5 88 60 71  
fridmar@hitataekni.is

IT BELIMO Servomotori S.r.l.  
Via Stezzano, 5  
24050 Zanicchi BG, Italy  
Tel. +39 035 67 26 82  
Fax +39 035 67 02 00  
info@belimo.it

KR HANMO Corporation  
3rd Floor, Yeosam Bldg. 648-23  
Gangnam-Ku, Seoul, Korea  
Tel. +822 3453 8225  
Fax +822 3453 8228

LB Energy Center (EC)  
Hamra, Leon Street, Shatilla,  
Bldg. 4th Floor,  
P.O. Box 113-6955  
Beirut, Lebanon  
Tel. +961 (0)1 35 38 23  
Fax +961 (0)1 35 38 23  
belimome@emirates.net.ae

NL/ BELIMO Servomotoren BV  
BE/ BENELUX  
LU Postbus 300, 8160 AH Epe  
Radeweg 25, 8171 MD Vaassen  
Netherlands  
Tel. +31 5 78 57 68 36  
Fax +31 5 78 57 69 15  
info@belimo.nl

NO BELIMO Spjeldmotorer A/S  
Konowgate 5  
0192 Oslo 1, Norway  
Tel. +47 22 70 71 71  
Fax +47 22 70 71 70  
info@belimo.no

PH BELIMO Actuators Philippines  
Rm.# 507 Anita Build., 5th Floor  
1300 Quezon Ave., Cor.South Ave.  
1103 Quezon City, Philippines  
Tel. +63 (2)373 5440  
Fax +63 (2)373 5424  
philippines@belimo.com.hk

RO SC Mano Construct srl  
Str. Camellei nr 5, sector 1  
Bucuresti, Romania  
Tel. +40 212 126 993  
Fax +40 212 126 995  
manoconstruct@fx.ro

RU BELIMO Servomotors  
Russia Ltd.  
Nizhnaya Pervomaiskaya,  
46 Bld 1, Office 303  
105203 Moscow, Russia  
Tel. +7 095 965 74 64  
Fax +7 095 965 74 73  
info@belimo.ru

SE BELIMO AB  
Hagerstens Allé 88  
129 37 Hagersten, Sweden  
Tel. +46 (0)8 464 07 00  
Fax +46 (0)8 97 85 75  
info@belimo.se

SY Philippe A. Jebran  
P.O. Box 7791  
Damascus, Syria  
Tel. +963 11 231 6586  
Fax +963 11 231 4052  
belimome@emirates.net.ae

TR BELIMO Otomasyon S.A.  
Keyap Sitesi No. 20  
TR-34775 Y.Dudullu  
Istanbul, Turkey  
Tel. +90 (0)216 527 98 70  
Fax +90 (0)216 527 98 71  
info@belimo.com.tr

TW Chianseng Enterprise Co. Ltd.  
2F, No. 21, Tong Fong Street  
Taipei, Taiwan  
Tel. +886 2 27 08 77 80  
Fax +886 2 27 02 90 90  
taiwan@belimo.com.hk

UA BELIMO Ukraine S.A.R.  
34-A, Ul. Yurkovskaya, Appt.Nº 2  
254080 Kiev, Ukraine  
Tel./Fax +380 44 463 7586  
comaster@belimo.kiev.ua

ZA BELIMO Actuators Southern Africa cc  
P.O. Box 2483  
Alberton 1450, South Africa  
Tel. +27 (0)11 868 5681  
Fax +27 (0)11 900 2673  
belimo@mega.co.za